


B14 PARTS LIST



Bold B14 Parts List

No	Part	No		Description
1	Bold B14 - Motor cover	28	Bold B14	Shaft
2	Bold B14 - Motor	29	Bold B14	Cowl
3	Bold B14 - Relay	30	Bold B14	Oil seal
4	Bold B14 - Contactor	31	Bold B14	Bearing
5	Bold B14 - Start button (green)	32	Bold B14	Bearing housing
6	Bold B14 - Stop button (red)	33	Bold B14	Bearing
7	Bold B14 - Contact block	34	Bold B14	Circlip
8	Bold B14 - Main body	35	Bold B14	Key
9	Bold B14 - S/S outlet	36	Bold B14	Washer
10	Bold B14 - Plastic Elbow	37	Bold B14	Nylock nut
11	Bold B14 - Motor Pulley	38	Bold B14	Outlet Blank
12	Bold B14 - Belt	39	Bold B14	Door spindle
13	Bold B14 - Large Pulley	40	Bold B14	Spindle retaining nut
14	Bold B14 - Base Cover	41	Bold B14	Door cam retaining nut
15	Bold B14 - Foot	42	Bold B14	Door cam
16	Bold B14 - Outlet Blank	43	Bold B14	Door cam retaining screw
17	Bold B14 - Water inlet complete (A.B.1)	44	Bold B14	Door frame
18	Bold B14 - Lid Knob	45	Bold B14	Door gasket
19	Bold B14 - Splash Cover Seal	46	Bold B14	Alloy door back
20	Bold B14 - Splash Cover	47	Bold B14	S/S door
21	Bold B14 - Loading Hopper	48	Bold B14	Handle retaining nut
22	Bold B14 - Abrasive Peeling Plate	49	Bold B14	Handle retaining screw
23	Bold B14 - Abrasive Liner	50	Bold B14	S/S door handle
24	Bold B14 - Nylon Brush	51	Bold B14	Roller retaining screw
25	Bold B14 - Top Rubber Seal	52	Bold B14	Nylon door roller
26	Bold B14 - Crosspin	53	Bold B14	Alloy door retaining screw
27	Bold B14 - Circlip			