


B56 PARTS LIST



Bold B56 Parts List

No.	Description
1	Bold B56 Cowl
2	Bold B56 Oil Seal
3	Bold B56 Top Bearing
4	Bold B56 Gearbox Gasket
5	Bold B56 Gearbox (Top)
6	Bold B56 Bearing (Bottom)
7	Bold B56 Drive Shaft
8	Bold B56 Woodruff Key
9	Bold B56 Gearbox Gasket
10	Bold B56 Main Gearwheel
11	Bold B56 Stud x 6
12	Bold B56 Gearbox (sump)
13	Bold B56 Bearing (Pinion)
14	Bold B56 Stud x 4
15	Bold B56 Motor Gasket
16	Bold B56 Oil Seal
17	Bold B56 Pinion
18	Bold B56 Motor
19	Bold B56 Oil Filler Screw
20	Bold B56 Crosspin
21	Bold B56 Circlips x 2
22	Bold B56 Bearing
23	Bold B56 Oil Drain Screw
24	Bold B56 Pinion Retaining Screw
25	Bold B56 Woodruff Key
26	Bold B56 Water Inlet complete (A B.I.)
27	Bold B56 Abrasive Peeling Plate
28	Bold B56 Abrasive Drum Liner
29	Bold B56 Top Rubber Seal (drum)
30	Bold B56 Main Body
31	Bold B56 Bottom Rubber Seal (drum)
32	Bold B56 Lid Knob
33	Bold B56 Splash Cover Seal
34	Bold B56 Splash Cover
35	Bold B56 Lifting Hooks
36	Bold B56 Loading Hopper
37	Bold B56 Plate Boss Screw
38	Bold B56 Plate Centre Boss
39	Bold B56 Plate Boss Nut
40	Bold B56 Plate Brush Retaining Screw
41	Bold B56 Plate Brush Retaining Nut

42	Bold B56 Nylon Brush
43	Bold B56 Liner Retaining Nut and Bolt
44	Bold B56 Door Spindle
45	Bold B56 Spindle Retaining Nut
46	Bold B56 Door Cam Retaining Nut
47	Bold B56 Door Cam
48	Bold B56 Door Cam Retaining Screw
49	Bold B56 Door Frame
50	Bold B56 Door Gasket
51	Bold B56 Alloy Door Back
52	Bold B56 S/S Door
53	Bold B56 Handle Retaining Nut
54	Bold B56 Handle Retaining Screw
55	Bold B56 S/S Door Handle
56	Bold B56 Roller Retaining Screw
57	Bold B56 Nylon Door Roller
58	Bold B56 Alloy Door Back Screw
59	Bold B56 Main Body Screw and Washer
60	Bold B56 S/S Pan complete with outlet
61	Bold B56 Pedestal Screw and Washer
62	Bold B56 Pedestal (Various Heights)